



MOLLE PANEL INSTALL INSTRUCTIONS

1. Line up your new molle panel against the surface you'll be mounting it to.
** If it helps you can use painters' tape to hold and adjust the panel as you level and adjust the panel to fit.
2. Mark the holes for mounting with a sharpie, or if on a black surface you can use your drill bit to lightly mark the surface
3. Using the provided aluminum spacers, place them in between the interior trim and the molle panel. Then using a Philips bit, install the 1" #10 stainless screw and the provided washer, and mount the panel to your interior trim. The screws will bite into the plastic and you shouldn't need to pre-drill.

PRO TIP – I like to use a Philips bit on a drill to get the screw started, and then finish tightening the screw with a Philips screwdriver until hand tightened

DO NOT OVER TIGHTEN THE SCREWS AS THIS WILL STRIP THE PLASTIC

If you have any questions during your install,
please email: NewHollandOverland@gmail.com