

DIY Antenna Swivel Mount

Install Instructions

1. Identify where you want your new swivel mount to go, make sure you have enough room with your antenna that it does not interfere with other mounted components on your roof rack.
(Its ideal to test fit your antenna with the bracket, and mock up on the vehicle)
2. With your antenna bracket identified, mark the x2 holes you will need to drill. One (x1) – 3/8” hole for the swivel bolt, and the one (x1) 1/4” hole for the quick release pin. (See diagram below for holes drilled)
 - **PRO-TIP – Use the aluminum bracket as the drill guide, this will ensure a tight fit with the roof rack and the swivel mount**
3. After holes are drilled, take the provided 3/8 bolt hardware, making sure to install the nylon washer in between the roof rack and the aluminum swivel bracket.

